



OPEN DIY PROJECTS

Serial1 = (oben neben USB) PlayUAV-OSD / Telemetrie
 Serial2 = UART3 Storm32 Controller (MavLink Gimbal-Control)
 Serial3 = UART4 GPS
 Serial5 = UART7 - NC, nur intern FTDI

- S1** Schalter 1 12V VTX
- S2** Schalter 2 12V Storm32
- S3** Umschalter 3 5V -Telem./ 5V-OSD